



1-866-LIFT NOW

Owner Introduction

Congratulations on becoming the owner of a new **FreedomLift**® – The Ultimate Tender Lift Solution! Please take the time to carefully review the following information to effectively use and operate your **FreedomLift**®. Also, have everyone who will operate the **FreedomLift**® read and understand this information as well.

OWNER'S MANUAL & WARRANTY

OPERATING INSTRUCTIONS

To lower the **FreedomLift**®

1. Press and hold the * button (lower left) on the Remote Control for 5 seconds – This will energize the system for 10 minutes.
2. Press the “DOWN ARROW” button on wireless remote control.

To raise the **FreedomLift**®

1. Press and hold the * button (lower left) on the Remote Control for 5 seconds – This will energize the system for 10 minutes.
2. Press the “UP” button on wireless remote control.
3. Release the “UP” button when the **FreedomLift**® is in the full upright and locked position.

CAUTION: PLEASE CAREFULLY REVIEW THE FOLLOWING

- When operating your boat, the tender **MUST BE SECURE AND TIGHTLY** strapped down to the Lift Arms in four ways – Two straps over the top of the tender to the Lift Arms, one strap from the bow of the tender to the Lift Arm and another from the stern of the tender to the Lift Arm. Check the tender frequently to be sure it remains properly secured. **FREEDOMLIFT® IS NOT RESPONSIBLE FOR ANY DAMAGE OR LOSS DUE TO IMPROPER SECURING OF THE TENDER.**
- Do not exceed the lifting / carrying capacity of the **FreedomLift**® (800 lbs). Do not let water accumulate in the tender; remember that a gallon of water weighs 8.33 lbs! Several gallons of water accumulated in the tender can add a **SIGNIFICANT** amount of weight. Be sure the tender self-bails or has a functioning bilge pump.
- Never operate the **FreedomLift**® with people in or on the PWC, Dinghy, or craft being lifted.

- Never operate the **FreedomLift®** with people in the water near the **FreedomLift®** and assure the **FreedomLift®** is in the upright and locked position prior to swimming near the **FreedomLift®**
- Never operate your boat unless the **FreedomLift®** is in the full upright locked position and property secured.
- Never operate the **FreedomLift®** when your boat is moving.
- When not in use, be sure the **FreedomLift®** is in the full upright and locked position.
- Never attempt to tow anything from the **FreedomLift®**
- Never operate with any engine running on the boat, PWC, or dinghy.
- Use caution when removing Lift Arms since your balance could be compromised. Lift Arms do not float. We suggest securing the Lift Arm with a line to a secure point on your boat when removing.
- Always secure your PWC or Dinghy to the **FreedomLift®** when not in use.
- Never operate in rough seas.
- Never attempt to remove a Lift Arm while in the water.
- Stay completely clear of the **FreedomLift®** when in operation.
- Never exceed the weight lifting capacity of your boats' transom or the **FreedomLift®**
- Never lift objects other than those intended to be lifted by the **FreedomLift®**
- The **FreedomLift®** is to be operated only by an adult who has read and fully understood this Owner's Manual. Never allow children to operate the lift.

MAINTENANCE:

Annual inspection of the lift, pump, hoses and fittings is required. Inspect all lift bolts and pins to assure nothing has loosened up, tighten as required. Inspect pump, hoses and fittings for leaks and take required corrective action by tightening parts or replacing damaged parts. **Be certain bolts on Lift Arm Bunks are very tight.**

Inspect the seals in the hydraulic cylinders to make sure they are not damaged and/or leaking. Should other items require maintenance, or replacement, please contact FreedomLift directly at 1-866-LIFT NOW.

Replace the hydraulic fluid as need or every 3 years.

Do NOT use any hydraulic fluid other than that provided by **FreedomLift®**. Using any other fluid can cause the lift to malfunction and will void all warranty. Use only Chevron Clarity Hydraulic Oil AW ISO 32.

The **FreedomLift®** anodes (aluminum) are CRITICAL in protecting the **FreedomLift®** from corrosion. Be certain to continuously monitor the anodes and REPLACE ANODES (10-12) AS REQUIRED – DO NOT LET THE ANODES SACRIFICE MORE THAN 50%. FreedomLift is not responsible for corrosion due to insufficient anode protection.

Be certain to ONLY use anti-fouling paint specifically formulated for use on Aluminum like Interlux Trilux 33. Use of non-compatible anti-fouling paint will cause significant damage to the **FreedomLift®**.

RE – PROGRAMMING THE WIRELESS REMOTE TRANSMITTER

TO PROGRAM:

1. Locate the grey Remote Control Receiver box (6.25” long by 3.14” high) on the Hydraulic Power Unit. Take the cover off (4 screws).
2. Locate the Program Switch s1 (small red button in the upper left corner approx. 1” left of the red LED light)
3. Press the Program Switch
4. Press the **DOWN** Button on the Remote Transmitter
5. Wait 10 seconds for the red LED light to flash
6. The Remote Transmitter is now programmed
7. Repeat steps 3-5 for another Remote Transmitter

TO CLEAR ALL PROGRAMMING:

Press and hold the Program Switch (described above) for approximately 10 seconds until the red LED light goes off.

Limited Warranty – **FreedomLift®** Hydraulic Transom Lift System

FreedomLift® provides a 2-year Limited Warranty for its Hydraulic Transom Lift System against defects in workmanship and materials on all aluminum structure and welds. This 2-year Limited Warranty is provided against defects in workmanship and materials for all other components. These components include but are not limited to: a) hydraulic pumps and controls, b) hoses, c) fittings, d) valves, e) cylinders, f) flow divider, g) removable lift arms, h) manual latch, and i) radio controls. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

This Limited Warranty applies from the date of purchase of the **FreedomLift®** for the applicable Limited Warranty periods and only under normal use and conditions and only to the original purchaser. Modifications to the **FreedomLift®** or any of its components, use of the **FreedomLift®** in salt water

without proper protective coating, overloading the **FreedomLift®** or other product abuse voids the Limited Warranty. **FreedomLift®** provides this Limited Warranty and makes no other warranties, expressed or implied. Some states provide certain implied warranties of merchantability and fitness for a particular purpose. To the extent that such implied warranties are applicable, the duration of such implied warranties shall be restricted to the duration of this Limited Warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This Limited Warranty provides for the repair or replacement of the defective workmanship and/or materials by **FreedomLift®** as determined in its absolute discretion. **FreedomLift®** is not liable for (and this Limited Warranty does not extend to) any consequential or incidental damages such as time lost, travel or damage to boat, tender, dinghy, PWC, or other property. **FreedomLift®** is not liable for damages to the **FreedomLift®** or injuries of any kind relating to or arising from the installation, removal, mis-use, or overloading of the **FreedomLift®**, negligence by others, or an Act of God, such as a hurricane, flood, or tornado. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Any claim under this Limited Warranty requires the following as a condition precedent:

- Contact with **FreedomLift®** before the expiration of the applicable Limited Warranty period with the following information: Model number of the product, date of purchase and place of purchase, description of the damage or defect and circumstances pertaining thereto and (where applicable) photograph of the damage or defect.
- Return, at the direction of **FreedomLift®** of the defective or damaged part to the **FreedomLift®** factory. **FreedomLift®** is not responsible for dealer service calls or freight costs to or from the **FreedomLift®** factory.
- **FreedomLift®**, at its sole option, will repair or replace any defective part covered by this Limited Warranty within 30 days (if reasonably possible) after receipt of the defective part in compliance with the above procedure and the terms of the Limited Warranty.

You can contact **FreedomLift®** at 1-866-LIFT NOW or 616-784-8759 with any questions or comments. **THANK YOU FOR CHOOSING THE FreedomLift®**

FreedomLift®
927 Alpine Commerce Park NW
STE 800
Grand Rapids, MI 49544
Toll Free 1-866-543-8669
Phone 616-784-8759
Fax 616-784-0349
Email service@freedomlift.com

www.freedomlift.com

